



Vigor2700Ge/e
ADSL2/2+ Firewall Router
Quick Start Guide

Version: 1.0

Date: 2005/11/07

Copyright Information

Copyright Declarations

Copyright 2005 All rights reserved. This publication contains information that is protected by copyright. No part may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language without written permission from the copyright holders.

Trademarks

The following trademarks are used in this document:

- Microsoft is a registered trademark of Microsoft Corp.
- Windows, Windows 95, 98, Me, NT, 2000, XP and Explorer are trademarks of Microsoft Corp.
- Apple and Mac OS are registered trademarks of Apple Computer Inc.
- Other products may be trademarks or registered trademarks of their respective manufacturers.

Safety Instructions and Approval

Safety Instructions

- Read the installation guide thoroughly before you set up the router.
- The router is a complicated electronic unit that may be repaired only by authorized and qualified personnel. Do not try to open or repair the router yourself.
- Do not place the router in a damp or humid place, e.g. a bathroom.
- Do not stack the routers.
- The router should be used in a sheltered area, within a temperature range of +5 to +40 Celsius.
- Do not expose the router to direct sunlight or other heat sources. The housing and electronic components may be damaged by direct sunlight or heat sources.
- Do not deploy the cable for LAN connection outdoor to prevent electronic shock hazards.
- Keep the package out of reach of children.
- When you want to dispose of the router, please follow local regulations on conservation of the environment.

Warranty

We warrant to the original end user (purchaser) that the router will be free from any defects in workmanship or materials for a period of two (2) years from the date of purchase from the dealer. Please keep your purchase receipt in a safe place as it serves as proof of date of purchase. During the warranty period, and upon proof of purchase, should the product have indications of failure due to faulty workmanship and/or materials, we will, at our discretion, repair or replace the defective products or components, without charge for either parts or labor, to whatever extent we deem necessary to restore the product to proper operating condition. Any replacement will consist of a new or re-manufactured functionally equivalent product of equal value, and will be offered solely at our discretion. This warranty will not apply if the product is modified, misused, tampered with, damaged by an act of God, or subjected to abnormal working conditions. The warranty does not cover the bundled or licensed software of other vendors. Defects which do not significantly affect the usability of the product will not be covered by the warranty. We reserve the right to revise the manual and online documentation and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

Be a Registered Owner

Web registration is preferred. You can register your Vigor router via <http://www.draytek.com>. Alternatively, fill in the registration card and mail it to the address found on the reverse side of the card.

Firmware & Tools Updates

Due to the continuous evolution of DrayTek G.SHDSL & Router technology, all routers will be regularly upgraded. Please consult the DrayTek web site for more information on newest firmware, tools and documents.

<http://www.draytek.com>

European Community Declarations

Manufacturer: DrayTek Corp.

Address: No. 26, Fu Shing Road, HuKou County, HsinChu Industrial Park, Hsin-Chu, Taiwan 303

Product: Vigor2700Ge/e Routers

DrayTek Corp. declares that Vigor2700Ge/e of routers are in compliance with the following essential requirements and other relevant provisions of R&TTE Directive 1999/5/EEC.

The product conforms to the requirements of Electro-Magnetic Compatibility (EMC) Directive 89/336/EEC by complying with the requirements set forth in EN55022/Class B and EN55024/Class B.

The product conforms to the requirements of Low Voltage (LVD) Directive 73/23/EEC by complying with the requirements set forth in EN60950.

The *Vigor2700 Ge/e* is designed for the WLAN 2.4GHz network throughput EC region, Switzerland, and the restrictions of France.

Regulatory Information

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the use is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device may accept any interference received, including interference that may cause undesired operation.

Table of Contents

1. Introduction.....	1
1.1 Panel Explanation	2
1.1.1 Front View for Vigor2700Ge	2
1.1.2 Rear View for Vigor2700Ge	2
1.1.3 Front View for Vigor2700e	3
1.1.4 Rear View for Vigor2700e.....	3
1.2 Package Content	4
2. Installing Your Vigor2700Ge/e Series Router	5
2.1 Hardware Installation.....	5
3. Configuring Web Pages	7
3.1 Basic Configuration	7
3.2 Wireless LAN Settings (for Vigor2700Ge only).....	11
3.2.1 Basic Wireless LAN Concept	11
3.2.2 General Settings.....	12
3.2.3 Security Settings	13
4. Trouble Shooting	15
4.1 Checking If the Hardware Status Is OK or Not	15
4.2 Checking If the Network Connection Settings on Your Computer Is OK or Not	15
4.3 Pinging the Router from Your Computer	18
4.4 Checking If the ISP Settings are OK or Not.....	20
4.5 Backing to Factory Default Setting If Necessary	21
4.6 Contacting Your Dealer	22
5. Specifications	23

1. Introduction

Targeting requirement for residential, SOHO (Small Office and Home Office) and business users, the Vigor2700Ge/e is an ADSL2/2+ enabled integrated access device. With downstream speed up to 12Mbps (ADSL2) or 24Mbps (ADSL2+), the Vigor2700Ge/e provides exceptional bandwidth for Internet access.



The available bandwidth depends on the Internet Service Provider.

To secure your network, the Vigor2700Ge/e provides an advanced firewall with advanced features, such as NAT with multi VPN pass-through, Stateful Packet Inspection (SPI) to offer network reliability by detecting and prohibiting malicious penetrating packets or DoS attacks, user-configurable web filtering for parental control against network abuse etc.


Vigor2700Ge is embedded with an 802.11g compliant wireless module which provides wireless LAN access with data rate as much as 54Mbps. As for data privacy of wireless network, the Vigor2700Ge can encode all transmissions data with standard WEP and industrial strength WPA2 (IEEE 802.11i) encryption. Additional features include Wireless Client List and MAC Address Control for maintaining control over user's authorization in your network, and Hidden SSID for being invisible to outside intruders scanning.

Characteristics

- Easy Internet-sharing of your broadband connection
- Robust firewall to help protect your network from external attacks


1.1 Panel Explanation

1.1.1 Front View for Vigor2700Ge




LED	Status	Explanation
ACT (Activity)	Blinking	The router is powered on and running properly.
	On	The router is powered on.
WLAN	Off	Wireless access point is turned off.
	On	Wireless access point is ready.
	Blinking	Wireless traffic goes through.
ADSL2+ Link	On	ADSL is show time.
	Blinking	The device starts handshaking.
ADSL2+ Data	Blinking	Data is transmitting.
LAN (1, 2, 3, 4)	Green	A normal connection is through its corresponding port.
	Blinking	Ethernet packets are transmitting.

1.1.2 Rear View for Vigor2700Ge




for Annex A



for Annex B

Interface	Description
ADSL 2+	Connector for accessing the Internet through ADSL 2+.
LAN 4 – 1	Connector for local networked devices.
Factory Reset	Restore the default settings. Usage: Turn on the router (ACT LED is blinking). Press the hole and keep for more than 5 seconds. When you see the ACT LED begins to blink rapidly than usual, release the button. Then the router will restart with the factory default configuration.
ON/OFF	Power Switch.
PWR	Connector for a power adapter with 7~7.5VDC.

1.1.3 Front View for Vigor2700e




LED	Status	Explanation
ACT (Activity)	Blinking	The router is powered on and running properly.
	On	The router is powered on.
ADSL2+ Link	On	ADSL is show time.
	Blinking	The device starts handshaking.
ADSL2+ Data	Blinking	DSL data is transmitting.
LAN (1, 2, 3, 4)	Green	A normal connection is through its corresponding port.
	Blinking	Ethernet packets are transmitting.

1.1.4 Rear View for Vigor2700e




for Annex A




for Annex B

Interface	Description
ADSL 2+	Connector for accessing the Internet through ADSL 2+.
LAN 4 – 1	Connector for local networked devices.
Factory Reset	Restore the default settings. Usage: Turn on the router (ACT LED is blinking). Press the hole and keep for more than 5 seconds. When you see the ACT LED begins to blink rapidly than usual, release the button. Then the router will restart with the factory default configuration.
ON/OFF	Power Switch.
PWR	Connector for a power adapter with 7~7.5VDC.


1.2 Package Content



1 Quick Start Guide



2 CD



3 RJ-45 Cable (Ethernet)

4 The type of the cable depends on the country that the router will be installed:



RJ-11 to RJ-11 Cable
(Annex A)

Or




RJ-11 to RJ-45 Cable
(Annex B)

Or




RJ-45 to RJ-45 Cable
(Annex B)


5 The type of the power adapter depends on the country that the router will be installed:




UK-type power adapter



EU-type power adapter



USA/Taiwan-type power adapter



AU/NZ-type power adapter

2. Installing Your Vigor2700Ge/e Series Router


This section will guide you to install the router through hardware connection and configure the router's settings through web browser.

2.1 Hardware Installation

Before starting to configure the router, you have to connect your devices correctly.

1. Connect the DSL interface to the external ADSL splitter with an ADSL line cable.
2. Connect one port of 4-port switch to your computer with a RJ-45 cable. This device allows you to connect 4 PCs directly.
3. Connect one end of the power cord to the power port of this device. Connect the other end to the wall outlet of electricity.
4. Power on the router.
5. Check the **ACT** and **ADSL2+**, **LAN** LEDs to assure network connections.

(For the detailed information of LED status, please refer to section 1.1.)



This page is left blank.

3. Configuring Web Pages

3.1 Basic Configuration

The **Quick Start Wizard** is designed for you to easily set up your router for Internet access. You can directly access the **Quick Start Wizard** via Web Configurator.

1. Make sure your PC connects to the router correctly.



Notice: You may either simply set up your computer to get IP dynamically from the router or set up the IP address of the computer to be the same subnet as **the default IP address of Vigor router 192.168.1.1**. For the detailed information, please refer to the later section - Trouble Shooting of the guide.

2. Open a web browser on your PC and type **http://192.168.1.1**. A pop-up window will open to ask for username and password. Do not type any word on the window and click **OK** for next screen.



Notice: If you fail to access to the web configuration, please go to “Trouble Shooting” for detecting and solving your problem.

3. Now, the **Main Screen** will pop up. Click **Quick Start Wizard**.

Vigor2700 Series
ADSL2/2+ Router

System Status

Model Name : Router
Firmware Version : v2.6.0RC3
Build Date/Time : Sep 20 2005 15:38:25

LAN	
MAC Address	: 00-50-7F-00-00-00
1st IP Address	: 192.168.1.1
1st Subnet Mask	: 255.255.255.0
DHCP Server	: Yes

WAN	
MAC Address	: 00-50-7F-00-00-01
Connection	: ---
IP Address	: ---
Default Gateway	: ---
DNS	: 194.109.6.66

Wireless LAN	
MAC Address	: 00-50-7F-00-00-00
Frequency Domain	: FCC
Firmware Version	:

Copyright (c) 2004, DrayTek Corp. All Rights Reserved.

4. Enter the login password on the field of **New Password** and retype it on the field of **Retype New Password**. Then click **Next** to continue.

Quick Start Wizard

1. Enter login password

Please enter an alpha-numeric string as your **Password** (Max 23 characters).

New Password

Confirm Password

< Back Next > Finish Cancel

5. On the next page as shown below, please select the appropriate Internet access type according to the information from your ISP or click **Auto detect** button to detect the related DSL parameters automatically. Then click **Next** for next step.

Quick Start Wizard

2. Connect to Internet

VPI

VCI

Protocol / Encapsulation

Fixed IP Yes No(Dynamic IP)

IP Address

Subnet Mask

Default Gateway

Primary DNS

Second DNS

< Back Next > Finish Cancel

Protocol / Encapsulation

PPPoA VC MUX

PPPoE LLC/SNAP

PPPoE VC MUX

PPPoA LLC/SNAP

PPPoA VC MUX

1483 Bridged IP LLC

1483 Routed IP LLC

1483 Bridged IP VC-Mux

1483 Routed IP VC-Mux (IPoA)

1483 Bridged IP (IPoE)

PPPoE or PPPoA: if you click PPPoE or PPPoA as the protocol, please manually enter the Username/Password provided by your ISP. Check **Always On** means Internet access is always on regardless of Internet usage. Then click **Next**. Besides, the protocol set here can be reviewed in the section of **DSL Modem Settings – Encapsulation** on the web page of **Internet Access – PPPoE/PPPoA**.

Quick Start Wizard

3. Set PPPoE / PPPoA

ISP Name

User Name

Password

Confirm Password

Always On

Idle Timeout Seconds

< Back Next > Finish Cancel

1483 Bridged: if you click 1483 Bridged, you will get the following page. Please type in all the information originally provided by your ISP. Then click **Next** for next step. Besides, the protocol set here can be reviewed in the section of **DSL Modem Settings – Encapsulation** on the web page of **Internet Access – MPoA (1483/2684)**.

Quick Start Wizard

2. Connect to Internet

VPI

VCI

Protocol / Encapsulation

Fixed IP Yes No(Dynamic IP)

IP Address

Subnet Mask

Default Gateway

Primary DNS

Second DNS

< Back Next > Finish Cancel

1483 Routed IP: if you click 1483 Routed IP, you will get the following page. Please type in all the information originally provided by your ISP. Then click **Next** for next step. Besides, the protocol set here can be reviewed in the section of **DSL Modem Settings – Encapsulation** on the web page of **Internet Access – MPoA (1483/2684)**.

Quick Start Wizard

2. Connect to Internet

VPI	8	Auto detect
VCI	35	
Protocol / Encapsulation	1483 Routed IP LLC	
Fixed IP	<input type="radio"/> Yes <input checked="" type="radio"/> No(Dynamic IP)	
IP Address		
Subnet Mask		
Default Gateway		
Primary DNS		
Second DNS		

< Back Next > Finish Cancel

- Now you can see the following screen. It indicates that the setup is complete. Different types of connection modes will have different summary. Click **Finish** and then restart the router. Afterward, you will enjoy surfing on the Internet.

Quick Start Wizard

4. Please confirm your settings:

VPI	: 8
VCI	: 35
Protocol / Encapsulation	: 1483 Route LLC
Fixed IP	: No
Primary DNS	:
Secondary DNS	:

< Back Next > Finish Cancel

3.2 Wireless LAN Settings (for Vigor2700Ge only)




For the user of Vigor2700e, please skip this section.

For operating Vigor2700Ge Series well, it is necessary for you to set the wireless LAN settings for using wireless function. Please read the following section carefully for configuring the settings for this router.

(The default value of Frequency Domain was set by factory depends on the reselling region.)

3.2.1 Basic Wireless LAN Concept

In an Infrastructure Mode of wireless network, Vigor wireless router plays a role as an **Access Point (AP)** connecting to lots of wireless clients or Stations (STA). All the STAs will share the same Internet connection with other wired hosts via Vigor wireless router.



3.2.2 General Settings

1. On the **Wireless LAN** group, select **General Settings**. The following page will be shown.

2. Check the box **Enable Wireless LAN** to enable the wireless function.
3. Select an appropriate wireless mode.

- Mixed (11b+11g)** The router can connect to IEEE802.11b and IEEE802.11g stations simultaneously. This is default settings. Choose this mode if you have no idea to change the mode.
- 11g-only** The router can connect to IEEE802.11g stations.
- 11b-only** The router can connect to IEEE802.11b stations.

4. Type in the name of the **SSID** and **Channel**. The default name for SSID is **default**. We suggest you change it to a particular name for your necessity.

SSID (service set identifier) It is used to name the wireless LAN for this router, and it must have the same content in client PC/notebook wireless card(s). SSID can be any text numbers or various special characters.

Channel It is a wireless channel for the router. The default channel is 6. You can change it to an appropriate one if the selected channel is under serious interference. Or you can select Auto to allow the system sensing available channel automatically.

3.2.3 Security Settings

1. On the **Wireless LAN** group, select **Security Settings**.

Wireless LAN >> Security Settings

Security Settings

Mode:

WPA:

Pre-Shared Key(PSK):

Type 8~63 ASCII character or 64 Hexadecimal digits leading by "0x", for example "cfgs01a2..." or "0x655abcd....".

WEP:

Key Length:

Key 1 :

Key 2 :

Key 3 :

Key 4 :

For 64 bit WEP key
Type 5 ASCII character or 10 Hexadecimal digits leading by "0x", for example "AB312" or "0x4142333132".

For 128 bit WEP key
Type 13 ASCII character or 26 Hexadecimal digits leading by "0x", for example "0123456789abc" or "0x30313233343536373839414243".

2. Select an appropriate encryption mode to improve the security and privacy of your wireless data packets.

Mode:

Pre-Shared Key(PSK):

Type 8~63 ASCII character or

Dropdown menu options: Disable, WEP, WPA/PSK, WPA2/PSK, Mixed(WPA+WPA2)/PSK

Disable	Turn off the encryption mechanism. For the security of your router, please select any one of the encryption mode here.
WEP	Accepts only WEP clients and the encryption key should be entered in WEP Key.
WPA/PSK	Accepts only WPA clients and the encryption key should be entered in PSK.
WPA2/PSK	Accepts only WPA2 clients and the encryption key should be entered in PSK.
Mixed (WPA+WPA2)/PSK	Accepts WPA and WPA2 clients simultaneously and the encryption key should be entered in PSK.

3. For **WPA** encryption, type in 8~63 ASCII characters or 64 Hexadecimal digits leading by 0x, for example "0123456789ABCD...." or "0x321253abcde....." on the

field of **Pre-Shared Key (PSK)**. WPA encrypts each frame transmitted from the radio using the Pre-Shared Key (PSK) which entered from this panel.

4. As to **WEP** encryption, select 64-bit or 128-bit as the encryption mode. For 64bits WEP key, type in 5 ASCII characters or 10 hexadecimal digitals leading by 0x, for example, ABCDE or 0x4142434445. And for 128bits WEP key, type in 13 ASCII characters or 26 hexadecimal digits leading by 0x, for example, ABCDEFGHIJKLM or 0x4142434445464748494A4B4C4D. Only one WEP key can be selected and allows user to type in the characters.
5. Click **OK** to save settings.

Be aware that for the communication, all wireless devices must support the same encryption bit length and share the same key. If WEP mode is selected, only one of four preset keys can be selected at one time.

4. Trouble Shooting

This section will guide you to solve abnormal situations if you cannot access into the Internet after installing the router and finishing the web configuration. Please follow sections below to check your basic installation status stage by stage.


- Checking if the hardware status is OK or not.
- Checking if the network connection settings on your computer are OK or not.
- Pinging the router from your computer.
- Checking if the ISP settings are OK or not.
- Backing to factory default setting if necessary.

If all above stages are done and the router still cannot run normally, it is the time for you to contact your dealer for advanced help.

4.1 Checking If the Hardware Status Is OK or Not

Follow the steps below to verify the hardware status.

1. Check the power line and WLAN/LAN cable connections.
Refer to “**2.1 Hardware Installation**” for details.
2. Turn on the router. Make sure the **ACT LED** blink once per second and the correspondent **LAN LED** is bright.



3. If not, it means that there is something wrong with the hardware status. Simply back to “**2.1 Hardware Installation**” to execute the hardware installation again. And then, try again.

4.2 Checking If the Network Connection Settings on Your Computer Is OK or Not

Sometimes the link failure occurs due to the wrong network connection settings. After trying the above section, if the link is still failed, please do the steps listed below to make sure the network connection settings is OK.

For Windows




The example is based on Windows XP. As to the examples for other operation systems, please refer to the similar steps or find support notes in www.draytek.com.


1. Go to **Control Panel** and then double-click on **Network Connections**.




2. Right-click on **Local Area Connection** and click on **Properties**.



3. Select **Internet Protocol (TCP/IP)** and then click **Properties**.




4. Select **Obtain an IP address automatically** and **Obtain DNS server address automatically**.



For MacOs

1. Double click on the current used MacOs on the desktop.
2. Open the **Application** folder and get into **Network**.
3. On the **Network** screen, select **Using DHCP** from the drop down list of Configure IPv4.




4.3 Pinging the Router from Your Computer

The default gateway IP address of the router is 192.168.1.1. For some reason, you might need to use “ping” command to check the link status of the router. **The most important thing is that the computer will receive a reply from 192.168.1.1.** If not, please check the IP address of your computer. We suggest you setting the network connection as **get IP automatically**. (Please refer to the section 4.2)

Please follow the steps below to ping the router correctly.

For Windows

1. Open the **Command Prompt** window (from **Start menu> Run**).
2. Type **command** (for Windows 95/98/ME) or **cmd** (for Windows NT/ 2000/XP). The DOS command dialog will appear.



```
Command Prompt
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

D:\Documents and Settings\fae>ping 192.168.1.1

Pinging 192.168.1.1 with 32 bytes of data:

Reply from 192.168.1.1: bytes=32 time<1ms TTL=255

Ping statistics for 192.168.1.1:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

D:\Documents and Settings\fae>_
```

3. Type **ping 192.168.1.1** and press [Enter]. If the link is OK, the line of “**Reply from 192.168.1.1:bytes=32 time<1ms TTL=25**” will appear.
4. If the line does not appear, please check the IP address setting of your computer.


For MacOs (Terminal)

1. Double click on the current used MacOs on the desktop.
2. Open the **Application** folder and get into **Utilities**.
3. Double click **Terminal**. The Terminal window will appear.
4. Type **ping 192.168.1.1** and press [Enter]. If the link is OK, the line of “**64 bytes from 192.168.1.1: icmp_seq=0 ttl=255 time=xxxx ms**” will appear.

```
Terminal — bash — 80x24
Last login: Sat Jan  3 02:24:18 on ttty1
Welcome to Darwin!
Vigor10:~ draytek$ ping 192.168.1.1
PING 192.168.1.1 (192.168.1.1): 56 data bytes
64 bytes from 192.168.1.1: icmp_seq=0 ttl=255 time=0.755 ms
64 bytes from 192.168.1.1: icmp_seq=1 ttl=255 time=0.697 ms
64 bytes from 192.168.1.1: icmp_seq=2 ttl=255 time=0.716 ms
64 bytes from 192.168.1.1: icmp_seq=3 ttl=255 time=0.731 ms
64 bytes from 192.168.1.1: icmp_seq=4 ttl=255 time=0.72 ms
^C
--- 192.168.1.1 ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 0.697/0.723/0.755 ms
Vigor10:~ draytek$
```

4.4 Checking If the ISP Settings are OK or Not

Click **Internet Access** group and then check whether the ISP settings are set correctly.



For PPPoE/PPPoA Users

1. Check if the **Enable** option is selected.
2. Check if **Username** and **Password** are entered with correct values that you **got from your ISP**.

Internet Access >> PPPoE / PPPoA

PPPoE / PPPoA Client Mode

PPPoE/PPPoA Client Enable Disable

DSL Modem Settings

Multi-PVC channel: Channel 1

VPI: 8

VCI: 35

Encapsulating Type: VC MUX

Protocol: PPPoA

Modulation: Multimode

PPPoE Pass-through

For Wired LAN

For Wireless LAN

ISP Access Setup

ISP Name: []

Username: []

Password: []

PPP Authentication: PAP or CHAP

Always On

Idle Timeout: 180 second(s)

IP Address From ISP: WAN IP Alias

Fixed IP: Yes No (Dynamic IP)

Fixed IP Address: []

* : Required for some ISPs

Default MAC Address

Specify a MAC Address

MAC Address : [00].[50].[7F].[00].[00].[01]

Scheduler(1-15)

[] , [] , [] , []

For MPoA Users

1. Check if the **Enable** option for Broadband Access is selected.

Internet Access >> MPoA (RFC1483/2684)

MPoA (RFC1483/2684) Mode
MPoA (RFC1483/2684) Enable Disable

DSL Modem Settings
Multi-PVC channel: Channel 2
Encapsulation: 1483 Bridged IP LLC
VPI: 8
VCI: 36
Modulation: Multimode

WAN IP Network Settings
 Obtain an IP address automatically
Router Name: *
Domain Name: *
 Specify an IP address
IP Address: 0.0.0.0
Subnet Mask: 0.0.0.0
Gateway IP Address:

RIP Protocol
 Enable RIP

Bridge Mode
 Enable Bridge Mode

* : Required for some ISPs
 Default MAC Address
 Specify a MAC Address
MAC Address : 00 . 50 . 7F . 00 . 00 . 01

DNS Server IP Address
Primary IP Address:
Secondary IP Address:

2. Check if all parameters of **DSL Modem Settings** are entered with correct value that provided by your ISP. Especially, check if the encapsulation is selected properly or not (it should be the same with the setting on **Quick Start Wizard**).
3. Check if **IP Address**, **Subnet Mask** and **Gateway** are set correctly (must identify with the values from your ISP) if you choose **Specify an IP address**.

4.5 Backing to Factory Default Setting If Necessary

Sometimes, a wrong connection can be improved by returning to the default settings. Try to reset the router by software or hardware.




Warning: After pressing **factory default setting**, you will lose all settings you did before. Make sure you have recorded all useful settings before you pressing. The password of factory default is null.

Software Reset


You can reset the router to factory default via Web page.

Go to **System Maintenance** and choose **Reboot System** on the web page. The following screen will appear. Choose **Using factory default configuration** and click **OK**. After few seconds, the router will return all the settings to the factory settings.



Hardware Reset

While the router is running (ACT LED blinking), press the **Factory Reset** button and hold for more than 5 seconds. When you see the **ACT** LED blinks rapidly, please release the button. Then, the router will restart with the default configuration.



After restore the factory default setting, you can configure the settings for the router again to fit your personal request.

4.6 Contacting Your Dealer

If the router still cannot work correctly after trying many efforts, please contact your dealer for further help right away. For any questions, please feel free to send e-mail to support@draytek.com.

5. Specifications

ADSL Compliant

- ANSI T1.413 Issue2)
- ADSL G.dmt.bis (G.992.1)
- ADSL2 G.dmt.bis (G.992.3)
- ADSL2+ (G.992.5)
- Reach extend ADSL (READSL)
- Up to 24Mbps downstream and 1Mbps upstream

ATM Protocols

- RFC2684 Multiple Protocol over AAL5
- RFC2516 PPP over Ethernet
- RFC2364 PPP over AAL5
- PPPoE pass through from LAN/WLAN
- Transparent bridge for MPoA

VLAN

- Part-based VLAN
- IGMP snooping*

Network Features

- IGMPv2 proxy
- DHCP client/relay/server
- Dynamic DNS
- SNTP client
- Call scheduling
- DNS cache/proxy
- UPnP
- Routing protocol:
 - Static routing
 - RIP V2

WLAN (for Vigor2700Ge only)

- IEEE802.11b/g compliant
- 64/128-bit WEP
- WPA/WPA2(IEEE802.11i)
- Wireless client list
- Hidden SSID
- MAC address access control
- Access point discovery *
- Wireless LAN isolation*
- WDS(Wireless Distribution System) *

Content Filter

- URL blocking
- Java Applet, Cookies, Active X blocking
- Key word blocking
- Specific file type blocking: compressed, executable, multimedia
- Time schedule control

Firewall Facilities

- IM blocking
- P2P blocking
- Multi-NAT, DMZ host, port-redirect/open port
- Stateful packet inspection
- DoS/DDoS protection
- User-configurable IP packet filtering

Router Management

- Web-based User Interface(HTTP)
- Command line interface (Telnet)
- Administration access control list
- Configuration backup/restore
- Build-in diagnostic function
- Firmware upgrade via TFTP
- Remote firmware upgrade via FTP
- Quick start wizard
- Logging via syslog

Power Consumption

- 8Watt Max.

(* future release)

Model comparison

	ADSL2/2+ Router	High Speed Wireless AP
Vigor2700Ge	✓	✓
Vigor2700e	✓	-